

## Flux thinner

Thinner on alcohol basis with foam stabilizing additives



PU	Delivery form
1 l	bottle
5 l	canister
25 l	canister
Other packages deliverable on request	

Product	Usable for the following FELDER fluxes
Thinner "VF-1"	All ISO-Flux® "ELR", "ELI" and "ELS"
Thinner "VF-2"	ISO-Flux® "EWL", the solder oils "E", "EL" and "Kolo" as well as all cable fluxes

### Setting of the optimum concentration of ISO-Flux® fluxes.

The FELDER flux-thinners serve to set the optimum concentration of FELDER ISO-Flux®- fluxes in soldering systems. During application in foaming or spraying devices there is a gradual increase in concentration which worsens the soldering result. Even in case of dip flux stations due to the large surface the solvent will be used up. As fluxes with a low content of solids have a small difference of density we recommend that the thinning-ratio should be determined via titration of the acid value (see FELDER titration set).